



# Thomas Montgomery Ltd


## Elb Range and Glo 150 & 155 Range




**Back Height Adjustment**  
Twist handle anticlockwise to release, slide backrest up or down and turn handle clockwise to lock



**Seat Height Adjustment**  
Lift right hand paddle whilst lifting weight off seat, lower by lifting paddle whilst seated.



**Back Angle Adjustment**  
Lift rear right hand paddle to release, adjust angle to desired position, push lever down to lock



**Seat Angle Adjustment (Elb st Only)**  
Lift paddle to release, adjust angle to desired position and push paddle down to lock.